



Technical Support Document

IMPORTANT - SENSOR ASSEMBLY INSTALLATION

To ensure that no damage to the sensor occurs, follow this installation procedure detailed below:



GENTLY HAND TIGHTEN SENSOR TO THE WATER PUMP UNTIL CONTACT IS FELT WITH THE INTERNAL WASHER. THEN USING A SMALL ADJUSTABLE WRENCH ON THE HEX NUT, TURN NO MORE THAN 1/2 TURN. TYPICALLY 1/4 TURN IS ONLY REQUIRED TO POSITION THE SENSOR VERTICAL.